

Woodstock Wall Display (HSWD) Mounting Instructions

Tools required

- 1) Medium Phillips screw driver

Display components

- 1) Display branch
- 2) Slatwall bracket
- 3) Flat wall bracket
- 4) Wood screws
- 5) S-hooks

Slatwall mounting instruction

- 1) Insert the stepped end of the slot-wall bracket into the groove in the slatwall.
- 2) Insert the bent end of the display branch into the tube on the bracket.
- 3) Tighten the Phillips screw on the bracket against the end of the display branch.
- 4) Use the S-hooks to hang chimes.

Flat wall mounting instructions

- 1) If the display is to be mounted on a solid wood flat surface you may use the four screws supplied to mount the flat wall bracket.
- 2) If you are mounting the display on a sheetrock or masonry wall please see your local hardware dealer for the appropriate fasteners.

