

# Birthstone Angel Display – CDBA

## Assembly Instructions

Your Birthstone Angel Display should contain the following:

- One 9.5" countertop base
- One metal pole
- Two pole clamps with thumbscrews
- One 3" header sign holder
- One printed header sign
- Two 5" disks
- Twelve snap-on pegs

To set-up your display, follow these directions in sequence:

1. Set the 9.5" base down on a table and insert the metal pole firmly into the base.
2. Slide one pole clamp onto the pole and position it approximately 9" from the top of the base. Insert the thumb screw into the clamp on the opposite end of the recessed nut and tighten securely.
3. Slide one of the disks (rib side down) onto the pole so that it is resting on the pole clamp. Repeat this process for the other disk making sure the top disk is flush with the top of the pole.
4. Remove the twelve pegs from the holder and press six pegs into each of the two disks in the following numbered slots - 1, 5, 9, 13, 17 & 21.
5. Place the 3" header sign holder securely into the top of the pole and slide your header sign into the slot. Your display should look similar to the one shown here.



Woodstock Percussion, Inc.  
Shokan, NY 12481  
info@WoodstockChimes.com  
WoodstockChimes.com  
Display Stand - MADE IN THE USA  
©2014 WPI

Woodstock Rainbow Makers™



From the makers of  
Woodstock Chimes®