


Woodstock Chime Tree Display

Storage Basket Assembly Instructions DISBKT

Parts List

Basket Side Panel


A



4pcs

Basket Bottom Panel

B



1pc

Socket Head Cap Screw

C




12pcs

Allen Wrench

D




Fig. 1.



Step 1.

Join 2 pieces of Basket Side Panel (A) using 1 of the Socket Head Cap Screws (C) by hand-tightening the screw clockwise. Continue building the box by adding the remaining 3 Basket Side Panels, as shown in **Fig. 1**.


Fig. 2.



Step 2.

When all sides are secure, flip the basket upside down and fit the Basket Bottom Panel (B) to form the bottom of the box. Insert one Socket Head Cap Screw (C) in the corner of each side panel as shown in **Fig. 1**. Now, go back and tighten all of the screws securely with the Allen Wrench included (D). Flip the box back over as the finished box in **Fig. 2**.

Fig. 3.



When using the Storage Basket with the DISCT2 Chime Tree Display as in **Fig. 3**, please be sure to place the basket on the display base and upright before adding the hanging arm assemblies.



Woodstock Percussion, Inc.

Shokan, NY 12481-5124 USA

800-422-4463 • 800-4-A-CHIME • Fax 800-974-0622

E-mail: woodstock@chimes.com • www.WoodstockChimes.com

DISBKTIns091713

Revised 09/17/13

©2013