


# Woodstock Chime Tree Display


## Assembly Instructions


### DISCT2



#### Step 2.

Insert 6 pieces Wire Arms (**F**) in holes in the top of each Metal Spool Adaptor (**D**) as shown in **FIG 2**. Adjust the levelers on the tube base bottom to make sure the display is level on the floor.





 **Woodstock Percussion, Inc.**  
Shokan, NY 12481-5124 USA  
800-422-4463 • 800-4-A-CHIME • Fax 800-974-0622  
E-mail: woodstock@chimes.com • www.WoodstockChimes.com

DISCT2Ins091813  
Revised 09/18/13

©2013

## Parts List

A.	Tube Base with Levelers.....	1 Pcs.
B.	Long Metal Upright .....	2 Pcs.
C.	Short Metal Upright.....	1 Pcs.
D.	Metal Spool Adaptor.....	2 Pcs.
E.	Wire Top.....	1 Pcs.
F.	Wire Arms.....	12 Pcs.
G.	Header Sign.....	1 Pc.
H.	Open End Wrench.....	1 Pc.



### Step 1.

Connect 2 pieces of Long Metal Upright (**B**) with Tube Base with Levelers (**A**) by hand-twisting the upright clockwise as shown. Continue building the display by adding 1 piece Metal Spool Adaptor (**D**), Short Metal Upright (**C**) and the remaining Metal Spool Adaptor (**D**) by hand-twisting each section clockwise as shown. Attach Wire Top (**E**) to top of the display assembly by turning Open End Wrench (**H**) clockwise as shown. Slide Header Sign (**G**) into Wire Top (**E**).