


Assembly Instructions

Music Collection Single Panel Display

COL2



Components

- 1) One Grid
- 2) Two Support Panels
- 3) Four 2-1/4 long slot head Screws, four Wing Nuts and four Washers
- 4) Three large Trays
- 5) Four small Trays
- 6) Ten 8-inch Hangers
- 7) Four 6-inch Hangers
- 8) One Header

Assembly

- 1) Assemble the support panels (2), one on each side of the grid (1). Place a washer on a screw, and insert the screw through one hole in the panel, and thread it between the two vertical rods on the side of the grid. Place another washer on the end of the screw projecting past the two rods and thread on the wing nut finger tight.
- 2) Repeat step 1 for the remaining three holes. Once all the screws are installed, they can be tightened using a screwdriver.
- 3) Install the header (8) by sliding it between the two wires at the top of the grid.
- 4) Install the trays (4 & 5) and hangers (6 & 7) on one or both sides of the display.



© Woodstock Percussion, Inc.
Shokan, NY 12481 USA
woodstock@chimes.com

10/03/08
©2008 WPI
File# 2074INS100308