

Woodstock



Gazebo Stand

Assembly Instructions

WGSC

Parts List

- A. Base Wires3 Pcs.
- B. Straight Bottom Wires..... 3 Pcs.
- C. Curved Top Wires3 Pcs.
- D. Flat Head Screws3 Pcs.
- E. Hook..... 1 Pc.
- F. Large Washer 1 Pc.
- G. Cap Nut 1 Pc.
- H. Ground Pegs..... 3 Pcs.
- I. Wrench 1 Pc.



Unthreaded Base Wire end (A1)

Threaded Base Wire end (A2)

Step 1 - Base Assembly

To form the triangle base of your **Gazebo Stand**, make sure that each Base Wire (A) is facing up as in image (A1). Join two sections by inserting a Flat Head Screw (D) into the wire ends making sure that an **Unthreaded** end of a Base Wire (A1) is over the top of a **Threaded** end (A2) of the other base wire. Join the remaining Base Wire section in the same way.

Step 2 - Upright Assembly

Twist one Straight Bottom Wire (B) into a threaded bushing located at one of the corners of the assembled base. Do this to all three Straight Bottom Wires. Next, twist one Curved Top Wire (C) into one of the Straight Bottom Wires of the base-upright assembly. Do this to all three Curved Top Wires.

Step 3 - Top Assembly

Gather the tops of the three Curved Top Wires, making sure to place the fittings in the proper order as they are attached at the tops of the wires - highest to lowest. From underneath, insert Hook (E) into top fittings. Place Large Washer (F) on this assembly, twist on the Cap Nut (G) and tighten with Wrench (I) provided.

Step 4 - Securing the Stand

To secure the Stand on the ground, insert Ground Pegs (H) through peg holes which are located at the three corners of the stand.